

This document illustrates how to implement a new Veculim installation, where Veculim is not installed on any other computers in the panel shop.

If you have already installed Veculim on another computer, then following the steps outlined in the [Workstation Setup](#)

Download the latest Veculim release from [www.veculim.com](http://www.veculim.com)

## Installing Veculim on your Server/Main Computer

Once you downloaded and started to run the install, an install wizard will appear with the welcome message.

### Install1

Click **Next** to proceed and display the License agreement window. Please indicate your acceptance by selecting the appropriate radio button and click **Next**.

### Install2

The default installation path will be displayed and can be changed if you choose to do so. Once the installation path has been specified, please click **Next**.

### Install3

A summary will be displayed for you to review and once satisfied, you can click **Next** button to begin the installation.

### Install4

### Install5

Once the installation has completed, select whether to create a Desktop Shortcut and whether you would like to run the application immediately. Then click **Finish**.

## Install6

**Next Recommended Step:** [Registering Veculim](#)